

How to Unregister for Google Cloud Print via CentreWare Internet Services

Effective from 1 January 2021, you will not be able to print using Google Cloud Print service.


By following the steps below, you can confirm or cancel your registration with Google Cloud Print using Google Cloud Print via CentreWare Internet Service (CWIS).

From your computer:

1. Start a web browser from a network-connected computer.



2. Enter the device IP address and then press Enter.



3. Enter the User name and passcode.

Note: By default, the Username is 11111 and the default passcode is x-admin.

4. Select the Properties tab.




5. Select **Connectivity > Protocols** from the left menu.



6. Select **Google Cloud Print**.

Note: Depending on the registration status, “Registered” will be displayed if you had Registered previously.



7. Click on **Cancel Registration** to unregister from Google Cloud Print.

